







After cutting out the dial plates fold on the dashed line.



Use a gnomon that has a very small diameter.


Print all pages at the same scale. Full scale is best. Do not use "Fit to Page".

Please follow the instructions provided with the full scale plans.



After cutting out the dial plates fold on the dashed line.

Use a gnomon that has a very small diameter.



Please follow the instructions provided with the full scale plans.